

數位訊號處理實驗 Digital Signal Processing Laboratory Lab 3 Pre-Processing of ECG Signals


ECG Signal and Interferences (1/2)



ECG Signal and Interferences (2/2)



60-Hz Power-Line Interference




ECG Noise Reduction

Noise types:


- Baseline wander (BW) (below 1Hz)
- 50 or 60 Hz power-line interference (PLI)
- Electromyogram (EMG)
- Motion artifact (MA)

Method	Noise Type
Adaptive Filter	BW, PLI, MA
Wavelet Transform	BW, EMG, MA
Empirical Mode Decomposition	BW, EMG, MA
Independent Component Analysis	MA
Moving Average	BW, (PLI), MA

Pre-Processing of ECG Signals to Locate R peaks (1/4)



Pre-Processing of ECG Signals (2/4): Why Squaring and Flattening



Pre-Processing of ECG Signals (3/4)

• (1) 60 Hz filtering:

$$x[i] = \frac{1}{M} \sum_{K=i-M/2}^{i+M/2-1} r[k]$$
. (Low pass filtering: moving average filtering)

(Low pass filtering: moving average filtering, FIR, How about IIR?)

• (2) Slope calculation:

http://oregonstate.edu/instruct/ch490/lessons/lesson11.htm

$$X_d[i] = 2x[i] + x[i-n] - x[i-2n] - 2x[i-3n].$$

(3) Squaring and flattening:

(High pass filtering: difference filtering, FIR, How about IIR?)

$$\hat{X}_d[i] = X_d^2[i], \qquad \hat{X}_{df}[i] = \frac{1}{N} \mathop{\mathring{o}}^{i+N/2-1} \hat{X}_d[k].$$
 old calculation: (Low pass filtering:

• (4) Adaptive threshold calculation:

(Low pass filtering: moving average filtering, FIR, How about IIR?)

$$TH = \frac{1}{S/2} \overset{n+S/4}{\overset{n-S/4}{\circ}} \hat{X}_{df}[i].$$

Pre-Processing of ECG Signals (4/4)

(4) Hard threshold:

$$\hat{X}_{dfT}[i] = \hat{X}_{df}[i] - TH,$$

$$\hat{\hat{X}}_{dfT}[i], \qquad \hat{X}_{df}[i] - TH > 0$$

$$\hat{\hat{X}}_{df}[i] - TH < 0$$

- (5) Slope local maximum detection
 - Find the time index *i* of the local maximum of the slope.
- (5) ECG local maximum detection:
 - Use the sample index i to find the local maximum of original ECG signal by applying a short searching range.
 - Searching region is set to be 0.1 second since normal QRS complex (5-40Hz) is about 80~100 ms duration.

Task 3 (in the Handout) Today

- Use 8 bits instead of 10 bits for the digitization of ECG signals. Design an algorithm and implement in Arduino to maintain the maximum dynamic range of the input ECG signal with 8-bit sampling.
 - From 10 bit to 8 bit sampling while maintaining the maximum dynamic range of the ECG signals can (1) reduce the data rate and (2) for example, utilize the full swing (full range) of a following DAC (8 bit).

Task 3 (in the Handout) Today

